

Liebert Series 600 UPS  
Monitored Points List

| Status              | Meters           |
|---------------------|------------------|
| Output Volts AB Lo  | Output Volts AB  |
| Output Volts AB Hi  | Output Volts BC  |
| Output Volts BC Lo  | Output Volts CA  |
| Output Volts BC Hi  | Output Current A |
| Output Volts CA Lo  | Output Current B |
| Output Volts CA Hi  | Output Current C |
| Output Current A Lo | Frequency Out    |
| Output Current A Hi | Battery Volts    |
| Output Current B Lo | Battery Current  |
| Output Current B Hi | Input Volt AB    |
| Output Current C Lo | Input Volt BC    |
| Output Current C Hi | Input Volt CA    |
| Frequency Out Lo    | Input Current A  |
| Frequency Out Hi    | Input Current B  |
| Battery Volts Lo    | Input Current C  |
| Battery Volts Hi    | KVA Out          |
| Battery Current Lo  |                  |
| Battery Current Hi  |                  |
| Input Volt AB Lo    |                  |
| Input Volt AB Hi    |                  |
| Input Volt BC Lo    |                  |
| Input Volt BC Hi    |                  |
| Input Volt CA Lo    |                  |
| Input Volt CA Hi    |                  |
| Input Current A Lo  |                  |
| Input Current A Hi  |                  |
| Input Current B Lo  |                  |
| Input Current B Hi  |                  |
| Input Current C Lo  |                  |
| Input Current C Hi  |                  |
| KVA Out Lo          |                  |
| KVA Out Hi          |                  |